

2014 MY BRZ - Federal/California Specification Vehicle

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																		REMARKS	
		Months x 1,000 km x 1,000 mi	3.0 4.8 3.0	7.5 12.0 7.5	15 24 15	22.5 36.0 22.5	30 48 30	37.5 60.0 37.5	45 72 45	52.5 84.0 52.5	60 96 60	67.5 108.0 67.5	75 120 75	82.5 132.0 82.5	90 144 90	97.5 156.0 97.5	105 168 105	112.5 180.0 112.5	120 192 120		132 220 132
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
3	Spark plug									R									R		
4	Drive belt(s)					I				I				I					I		
5	Fuel system, lines & connections					I				I				I					I		Note 6 & 7
6	Air cleaner element					R				R				R					R		Note 8
7	Cooling system, hoses & connections					I				I				I					I	P	Note 11
8	Engine coolant		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter																		Note 11
9	Automatic Transmission Fluid					I				R				I					R		Note 4 & 9
10	Rear differential gear oil			I		I				R		I		I					R		Note 3
11	Brake lines, operation of parking & service brake system			I		I				I		I		I					I		Note 6
12	Brake fluid / clutch fluid (MT Only)					R				R				R					R		Note 5
13	Disc brake pad & disc, front & rear axle boots & axle shaft joint		I			I				I		I		I					I		Note 6
14	Brake linings & drums					I				I				I					I		Note 6
15	Steering & suspension			I		I				I		I		I					I		Note 6
16	Wheel bearing									I									I		
17	Transmission lubricants (gear oil)				I					I				I					I		Note 3
18	Rotate and inspect tires		P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 10
19	Fuel filter											R									Note 2 & 7
20	Clutch operation			I		I				I		I		I					I		
21	HVAC system A/C filter		Replace every 15 months or 24,000 km (15,000 miles)																		Note 8

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.

2014 MY Forester - Federal/California Specification Vehicle

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																		REMARKS		
		Months x 1,000 km x 1,000 mi	3.0 4.8 3.0	7.5 12.0 7.5	15 24 15	22.5 36.0 22.5	30 48 30	37.5 60.0 37.5	45 72 45	52.5 84.0 52.5	60 96 60	67.5 108.0 67.5	75 120 75	82.5 132.0 82.5	90 144 90	97.5 156.0 97.5	105 168 105	112.5 180.0 112.5	120 192 120		132 220 132	
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1	
2	Engine oil filter			R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
3	Spark plug									R										R		
4	Drive belt(s)						I			I					I					I		
5	Fuel systems, lines & connections						I			I					I					I	Note 6 & 7	
6	Fuel filter												R								Note 2 & 7	
7	Air cleaner element						R			R				R						R	Note 8	
8	Cooling system, hoses & connections						I			I				I						I	Note 11	
9	Engine coolant		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter																		Note 11	
10	Clutch operation				I		I		I		I		I		I		I		I			
11	Transmission gear oil						I			I				I						I	Note 3	
12	CVT fluid						I			I				I						I	Note 4 & 9	
13	Front & rear differential gear oil						I			I				I						I	Note 3	
14	Brake lines, operation of parking & service brake systems				I		I		I		I		I		I		I		I		Note 6	
15	Brake fluid / clutch fluid (MT Only)						R			R				R						R	Note 5	
16	Disc brake pad & disc, front & rear axle boots & joints				I		I		I		I		I		I		I		I		Note 6	
17	Steering & suspension				I		I		I		I		I		I		I		I		Note 6	
18	Wheel bearing									I										I		
19	Rotate & inspect tires			P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 10
20	HVAC system A/C filter		Replace every 12 months or 12,000 km (7,500 miles)																		Note 8	

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.

2014 MY Impreza - Federal/California Specification Vehicle

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																		REMARKS		
		Months x 1,000 km x 1,000 mi	3.0 4.8 3.0	7.5 12.0 7.5	15 24 15	22.5 36.0 22.5	30 48 30	37.5 60.0 37.5	45 72 45	52.5 84.0 52.5	60 96 60	67.5 108.0 67.5	75 120 75	82.5 132.0 82.5	90 144 90	97.5 156.0 97.5	105 168 105	112.5 180.0 112.5	120 192 120		132 220 132	
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1	
2	Engine oil filter			R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
3	Spark plug									R										R		
4	Drive belt(s)					I				I				I						I		
5	Fuel systems, lines & connections					I				I				I						I	Note 6 & 7	
6	Fuel filter											R									Note 2 & 7	
7	Air cleaner element					R				R				R						R	Note 8	
8	Cooling system, hoses & connections					I				I				I						I	Note 11	
9	Engine coolant		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter																		Note 11	
10	Clutch operation			I		I		I		I		I		I		I		I		I		
11	Transmission gear oil					I				I				I						I	Note 3	
12	CVT fluid					I				I				I						I	Note 4 & 9	
13	Front & rear differential gear oil					I				I				I						I	Note 3	
14	Brake lines, operation of parking & service brake systems			I		I		I		I		I		I		I		I		I	Note 6	
15	Brake fluid / clutch fluid (MT Only)					R				R				R						R	Note 5	
16	Disc brake pad & disc, front & rear axle boots & joints			I		I		I		I		I		I		I		I		I	Note 6	
17	Steering & suspension			I		I		I		I		I		I		I		I		I	Note 6	
18	Wheel bearing									I										I		
19	Rotate & inspect tires		P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 10
20	HVAC system A/C filter		Replace every 12 months or 12,000 km (7,500 miles)																		Note 8	

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.

2014 MY Impreza WRX/STI - Federal/California Specification Vehicles

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																		REMARKS	
		Months x 1,000 km x 1,000 mi	3.0 4.8 3.0	7.5 12.0 7.5	15 24 15	22.5 36.0 22.5	30 48 30	37.5 60.0 37.5	45 72 45	52.5 84.0 52.5	60 96 60	67.5 108.0 67.5	75 120 75	82.5 132.0 82.5	90 144 90	97.5 156.0 97.5	105 168 105	112.5 180.0 112.5	120 192 120		132 220 132
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
3	Spark plug									R									R		
4	Drive belt(s)					I				I				I		R					
5	Timing belt					I				I				I		R					
6	Fuel systems, lines & connections					I				I				I					I		Note 6 & 7
7	Fuel filter									R									R		Note 2 & 7
8	Air cleaner element					R				R				R					R		Note 8
9	Cooling system, hoses & connections					I				I				I					I		Note 11
10	Engine coolant		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter																		Note 11
11	Clutch operation			I		I		I		I		I		I		I		I		I	
12	Transmission gear oil					I				I				I					I		Note 3
13	Front & rear differential gear oil					I				I				I					I		Note 3
14	Brake lines, operation of parking & service brake systems			I		I		I		I		I		I		I		I		I	Note 6
15	Brake fluid / clutch fluid (MT Only)					R				R				R					R		Note 5
16	Disc brake pad & disc, front & rear axle boots & joints			I		I		I		I		I		I		I		I		I	Note 6
17	Steering & suspension			I		I		I		I		I		I		I		I		I	Note 6
18	Wheel bearing									I										I	
19	Rotate & inspect tires		P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 10
20	HVAC system A/C filter		Replace every 12 months or 12,000 km (7,500 miles)																		Note 8

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.

2014 MY Legacy/Outback - Federal/California Specification Vehicles

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																		REMARKS			
		Months x 1,000 km x 1,000 mi	3.0	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120		132		
			4.8	12.0	24	36.0	48	60.0	72	84.0	96	108.0	120	132.0	144	156.0	168	180.0	192		220		
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	3.6L Note 1	
				R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	2.5L Note 1
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	3.6L Note 1	
				R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	2.5L Note 1
3	Spark plug										R										R		
4	Drive belt(s)						I				I					I		R					
5	Fuel systems, lines & connections						I				I					I					I	Note 6 & 7	
6	Fuel filter										R										R	Note 2 & 7	
7	Air cleaner element						R				R					R					R	Note 2 & 12	
8	Cooling system, hoses & connections						I				I					I					I	Note 11	
9	Engine coolant		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter																		Note 11		
10	Clutch operation				I		I			I			I			I					I		
11	Transmission gear oil						I				I				I						I	Note 3	
12	Automatic Transmission Fluid						I				I				I						I	Note 4 & 9	
13	CVT fluid						I				I				I						I	Note 4 & 9	
14	Front & rear differential gear oil						I				I				I						I	Note 3	
15	Brake lines, operation of parking & service brake systems				I		I			I			I		I		I				I	Note 6	
16	Brake fluid / clutch fluid (MT Only)						R				R				R						R	Note 5 & 12	
17	Disc brake pad & disc, front & rear axle boots & joints			I			I			I			I		I		I				I	Note 6	
18	Steering & suspension				I		I			I			I		I		I				I	Note 6	
19	Wheel bearing										I										I		
20	Rotate & inspect tires			P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 10
21	HVAC system A/C filter		Replace every 15 months or 24,000 km (15,000 miles)																		Note 8		

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.

2014 MY Tribeca - Federal/California Specification Vehicle

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																		REMARKS	
		Months x 1,000 km x 1,000 mi	3.0 4.8 3.0	7.5 12.0 7.5	15 24 15	22.5 36.0 22.5	30 48 30	37.5 60.0 37.5	45 72 45	52.5 84.0 52.5	60 96 60	67.5 108.0 67.5	75 120 75	82.5 132.0 82.5	90 144 90	97.5 156.0 97.5	105 168 105	112.5 180.0 112.5	120 192 120		132 220 132
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
3	Spark plug									R									R		
4	V-belt						I			I					I		R				
5	Fuel systems, lines & connections						I			I					I					I	Note 6 & 7
6	Fuel filter									R										R	Note 2 & 7
7	Air cleaner element						R			R					R					R	Note 8
8	Cooling system, hoses & connections						I			I					I					I	Note 11
9	Engine coolant		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter																		Note 11
10	Automatic Transmission Fluid						I			I					I					I	Note 4 & 9
11	Front & rear differential gear oil						I			I					I					I	Note 3
12	Brake lines, operation of parking & service brake systems				I		I		I		I		I		I		I		I		Note 6
13	Brake fluid / clutch fluid (MT Only)						R			R					R					R	Note 5
14	Disc brake pad & disc, front & rear axle boots & joints				I		I		I		I		I		I		I		I		Note 6
15	Steering & suspension				I		I		I		I		I		I		I		I		Note 6
16	Wheel bearing									I										I	
17	Rotate & inspect tires		P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 10
18	SRS airbag system		Inspect every 10 years																		
19	HVAC system A/C filter		Replace every 16 months or 24,000 km (15,000 miles)																		Note 8

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.

2014 MY XV Crosstrek - Federal/California Specification Vehicle

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																			REMARKS	
		Months x 1,000 km x 1,000 mi	3.0 4.8 3.0	7.5 12.0 7.5	15 24 15	22.5 36.0 22.5	30 48 30	37.5 60.0 37.5	45 72 45	52.5 84.0 52.5	60 96 60	67.5 108.0 67.5	75 120 75	82.5 132.0 82.5	90 144 90	97.5 156.0 97.5	105 168 105	112.5 180.0 112.5	120 192 120	132 220 132		
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1	
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1	
3	Spark plug									R										R		
4	Drive belt(s)					I				I					I					I		
5	Fuel systems, lines & connections					I				I					I					I	Note 6 & 7	
6	Fuel filter											R									Note 2 & 7	
7	Air cleaner element					R				R					R					R	Note 8	
8	Cooling system, hoses & connections					I				I					I					I	Note 11	
9	Engine coolant		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter																		Note 11	
10	Clutch operation			I		I		I		I		I		I		I		I		I		
11	Transmission gear oil					I				I					I					I	Note 3	
12	CVT fluid					I				I					I					I	Note 4 & 9	
13	Front & rear differential gear oil					I				I					I					I	Note 3	
14	Brake lines, operation of parking & service brake systems		I			I		I		I		I		I		I				I	Note 6	
15	Brake fluid / clutch fluid (MT Only)					R				R				R						R	Note 5	
16	Disc brake pad & disc, front & rear axle boots & joints		I			I		I		I		I		I		I				I	Note 6	
17	Steering & suspension			I		I		I		I		I		I		I				I	Note 6	
18	Wheel bearing									I										I		
19	Rotate & inspect tires		P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 10
20	HVAC system A/C filter		Replace every 12 months or 12,000 km (7,500 miles)																		Note 8	

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.