How to check software version of head unit software

1. **Go to settings on the vehicle infotainment screen.**

2. **Go to the "General" screen**
3. **Select "System Information"**

4. **The current software version will be displayed. The latest version as of September 2018 is UO.18.22.20 for non-navigation units and UO.18.30.20 for navigation equipped units.**

System Information

Software Version: Rel_UO.18.30.20

Navi Database Version: USA Canada and Mexico_991_6759_9121

OK